



ORIGIN
ACOUSTICS®

Director Collection

D50 Series & DSUB6X2 Subwoofer
Cut-Out Template: 5 7/8" (150mm)



When you have decided on the location for the speaker, trace this template lightly in pencil where the hole should be. Punch out the round template. If unsure on whether there may or may not be obstructions above the planned location, use a keyhole or drywall saw to drill a 1/8" hole in the center of the template, then insert a bent coat hanger through the hole to feel for obstructions.

www.originacoustics.com

sales@originacoustics.com

844.674.4461

8:00AM - 5:00PM (PT) Mon - Fri



ORIGIN
ACOUSTICS®

Director Collection

D50 Series & DSUB6X2 Subwoofer
Cut-Out Template: 5 7/8" (150mm)



When you have decided on the location for the speaker, trace this template lightly in pencil where the hole should be. Punch out the round template. If unsure on whether there may or may not be obstructions above the planned location, use a keyhole or drywall saw to drill a 1/8" hole in the center of the template, then insert a bent coat hanger through the hole to feel for obstructions.

www.originacoustics.com

sales@originacoustics.com

844.674.4461

8:00AM - 5:00PM (PT) Mon - Fri