

240 mm

255 mm



ORIGIN
ACOUSTICS®

DSUB8
Director Collection

Drill Hole Template: 24 x 9 7/16" (610 x 240mm)

Hold the template to the joist that you plan on attaching the subwoofer enclosure to. Drill six holes through the marked locations on the template using a 5/16"(8mm) drill bit. Face the enclosure's rubber damping pad towards the joist and secure it in place with the supplied lag screws and washers. We recommend that one person holds the subwoofer in place while another tightens the screws to secure the DSUB6 to the joist.

www.originacoustics.com
techsupport@originacoustics.com
844.674.4461
8:00AM - 5:00PM (PT) Mon - Fri

510 mm

610.0 mm

190 mm