



BAYONET RING

BZ3 | BZ5 | BZ68 | BZ10 | INSTALLATION MANUAL




TABLE OF CONTENTS

Introduction	1
What's Included	2
Bayonet Ring Features	2
Releasing Speaker from Bayonet Ring	4
Installing Bayonet Ring into Ceiling	6
Installing Speaker into Bayonet Ring	8
Releasing Bayonet Ring from Ceiling	10
Wire Routing	11
BC68 Cover Plate	12
Troubleshooting	13
Technical Assistance	13
Return Process	13




1. Introduction


Thank you for purchasing our Bayonet Ring. At Origin Acoustics, we take pride in providing you with a high quality product. All of Origin Acoustics' speakers are designed to have excellent sound quality, longevity, and a simple installation process.

This instruction booklet covers the necessary information for a smooth installation, including: the tools you will need, step-by-step instructions for installation, troubleshooting tips for any errors that may occur, and all warranty information. If for any reason you experience problems or if you have installation questions please call us at (844) 674-4461. Hours of operation are 8:00am to 5:00pm (Pacific Time), Monday through Friday.

2. What's Included





Bayonet Ring



Manual

3. Bayonet Ring Features





A) BAYONET RING To be inserted within in-ceiling hole

B) RING - LOCK Locks speaker into place inside Bayonet Ring. (Lift to release speaker. Lower to Lock.

C) BAYONET RAILS The Zip-Klip™ Grips are raised & lowered along these rails.

D) ZIP - KLIP™ GRIPS Provide secure grip against drywall. With 2 finger grooves to pull down and lower. Zip-Klip™ Mounting System (Patent #9591390).

E) RELEASE TABS Press BLACK tabs inwards to release grip and raise Zip-Klip™.



F) LOCK GROOVES Used to ALIGN & LOCK speaker inside Bayonet Ring.

Releasing Speaker from Bayonet Ring



The speaker will arrive installed inside the Bayonet Ring.

To release the speaker, follow these steps:



1) UNLOCK RING-LOCK TAB ON BAYONET RING:



2) ROTATE SPEAKER 15° COUNTER-CLOCKWISE, HOLDING THE BAYONET RING IN PLACE, UNTIL YOU FEEL THAT IT IS UNLOCKED. YOU WILL SEE THAT THE GROOVES BETWEEN THE SPEAKER AND BAYONET RING ARE NO LONGER ALIGNED. HERE, THE SPEAKER CAN BE LIFTED OUT FROM THE BAYONET RING.

2a**2b**


Twist Speaker
15°
Anti-Clockwise
to UnLock

**3**


Lift Speaker
out of
Bayonet
Ring

Installing Bayonet Ring into Ceiling


1) CUT IN-CEILING HOLE THROUGH DRYWALL CEILING.




PUSH THE ZIP-KLIP™ INWARDS (FROM THE TOP), JUST ENOUGH, SO THE RAILS FIT THROUGH THE CEILING HOLE OPENING, AND PLACE THE BAYONET RING THROUGH IN-CEILING HOLE.




2) ONCE BAYONET RING IS INSIDE CEILING HOLE, REACH THROUGH AND PLACE 2 FINGERS ON THE GROOVES OF THE ZIP-KLIP™.



2b



2c




PULL DOWN ON THE ZIP-KLIP™, UNTIL IT GRIPS THE DRYWALL SECURELY.

3) REPEAT PROCESS WITH ALL FOUR (4) ZIP-KLIPS™.

NOW BAYONET RING IS SECURELEY FASTENED TO DRYWALL CEILING.

Installing Speaker into Bayonet Ring


1) CONNECT SPEAKER WIRES AND PLACE THE SPEAKER INTO THE BAYONET RING. THE SPEAKER KNOBS WILL FIT INTO THE BAYONET RING SHELF OPENING.



2) PUSH THE SPEAKER UPWARDS INTO THE BAYONET RING AND ROTATE THE SPEAKER CLOCKWISE UNTIL YOU FEEL IT LOCK INTO PLACE.

3) TO LOCK SPEAKER INTO BAYONET RING, PUSH THE RING-LOCK INWARDS.


When the speaker is correctly installed into the Bayonet Ring, the speaker groove lines will be aligned to the matching groove lines of the Bayonet Ring. Then you will be able to move the Ring-Lock Tab inwards, towards the center of the speaker. When the Ring-Lock Tab is fully closed, it will lay flush with the perimeter of the Bayonet Ring.




Releasing Bayonet Ring from Ceiling

LOOSEN ZIP-KLIP™ GRIPS TO RELEASE BAYONET RING FROM CEILING HOLE:

1) PRESS ON BOTH RELEASE TABS, ON THE INSIDE OF EACH ZIP-KLIP™.



2) SLIDE THE ZIP-KLIP™ UPWARDS ALONG THE RAIL, UNTIL YOU REACH THE TOP.



3) REPEAT STEPS 1 & 2 TO THE REST OF THE ZIP-KLIPS™.

Wire Routing

Plan how you'll route the wire to the desired speaker location. There are several methods for routing the wire, and you may need to combine several of them.

Behind the Baseboard

The wire can be routed behind the baseboard by cutting a groove out of the back of the baseboard, or by buying special baseboard designed for concealing wires.

Through Walls

When running wires through a wall, be sure to avoid all obstacles such as AC wiring, pipes, and ducts.

Attic or Basement

When available, you can route the wire through an attic or crawlspace.

Under the Carpet

One option is to lift up the carpet and route "tape wire" under the carpet.

For New Construction

If these speakers are being installed in a new home during construction, the installation process will be a bit different (although much simpler). For these situations, it's recommended you purchase a bracket. Instructions on how to install the speakers are provided with the bracket, or can be found on our website. Visit www.originacoustics.com for more information.

BC68 Cover Plate

Origin Acoustics offers:

- **BC68**
- **BZ68BC-8 BUNDLE (8-Pack)**

The Bayonet Cover from Origin Acoustics gives you the flexibility you need. If you are wiring a new house, or retro-fitting an established home, with the BC68 there's no need to install the speakers until the client is ready for them.

With the BC68 Cover Plate, you can prewire a home, precut and install the bayonet ring, all before a pressure test, keep unwanted substances out of your clients' attic, and protect your wiring before the final install.

Each cover provides a clear space for the Dealer Sticker to be placed onto the cover plate, ensuring future business.



Troubleshooting

Problem	Possible Cause
Can't Take speaker out of Bayonet Ring	Ensure that the RING-LOCK is not ENGAGED . Move Ring Lock Tab Outwards (AWAY from Speaker) to UNLOCK .

Technical Assistance

If you have any questions or concerns about installing or using this product, you can reach us through one of the following methods:

Phone: (844) 674-4461

Hours of operation: 8:00am - 5:00pm (Pacific Time), Mon - Fri

Email: sales@originacoustics.com

If you are having technical trouble, please include the model number and briefly explain what steps you took to resolve the problem in your email, or be prepared to answer these questions over the phone. If you are considering returning the product, it's required that you contact Origin Acoustics prior to any return attempts. This way we can determine if the issue can be resolved without returning the product, or if needed we can provide instructions and support for the return process.

Return Process

Before making any return attempts, it is required that you first contact Origin Acoustics. Return product to Origin Acoustics or your dealer, either in person or by mail. It's preferable if the product is returned in the original packaging. If this isn't possible, the customer is responsible for insuring the shipment for the full value of the product.



12-05-2022

6975 S Decatur BLVD, Las Vegas, NV 89118 • www.originacoustics.com • 844-674-4461

©2022 Origin Acoustics. All copyrighted, trademarked and patented elements mentioned herein are the sole property of Origin Acoustics.