VOLUME CONTROL
VCOAPROR

ORIGIN
PRO

WARNING
IMPORTANT SAFETY INSTRUCTIONS:

- For internal use only. Do NOT use in wet locations.
- This product is to be installed or used with products that have a 3V3 GPIO.
- This product is NOT to be connected to the amplifier output.

What's Included

1) 1 x VCOAPROR Volume Control
2) 3 x Wall Plates
3) 3 x Covers
4) 2 x Volume Control Screws
   (6-32 x 3/4 in)
5) 6 x Wall Plate Screws
6) 3 x Control Knobs
7) Start Guide

Required Tools

A) Phillips Screwdriver
B) Slotted 'Flat head' Screwdriver
C) Wire Stripper

Please visit www.originpro.com or scan this QR code using your smart device for the most up to date safety information and full installation instructions for this product.

All warranties and warranty conditions are subject to change. Please refer to www.originpro.com for the latest information.

Scan the QR Code on the reverse of this page for full instructions for this product.

DIAGRAM 1A

DIAGRAM 1B

Installing the Wire Connection:

1) Make sure the Amplifier is turn OFF.
2) Strip 1/4 inch (5mm) of the insulation off both ends of the wire.
3) On the Volume Control 3P Connector, connect the 3 wires. (DIAGRAM 1A)
4) On the wire going to the amplifier, connect the 3 wires to the GPIO connector as indicated on the connection diagram above. (DIAGRAM 1B)

DIAGRAM 2A   **DIAGRAM 2B**

Installing the Wall Plate:

1) Use the x 2 Volume Control Screws (6-32 x 3/4 in) and Phillips Screwdriver to attach the VCOAPRO Volume Control securely to the Wall Gang Box. (DIAGRAM 2A)
2) Use the x 4 Wall Plate Screws and Slotted 'Flat head' Screwdriver to attach the Wall Plate securely over the Control. (DIAGRAM 2B)

Volume Control Set Up (Amplifier):

1) Connect to the Amplifier using WiFI, and press the "SETTINGS" tab.
2) Select the "GPIO" option and in the GPIO Setting menu, select the Pin number (4, 5,6 or 7) that you connected the "CTRL" wire of the Volume Control on the GPIO connector into the back of the amplifier (DIAGRAM 1B).